

DMX function

Graphite 300 AD3552

DMX functions with OPTION 2 = OFF

Channel	Function	Value	Description
1	Lamp	0-63	Lamp ON
		64-127	Reset
		128-255	Lamp OFF + Reset
2	Blackout Dimmer Strobe	0-5	Shutter Closed
		6-127	0-100% proportional colour control
		128-159	Shutter open
		160-179	Strobe effect speed 1
		180-199	Strobe effect speed 2
		200-219	Strobe effect speed 3
		220-239	Strobe effect speed 4
240-255	Shutter open		
3	Yellow	0-255	0-100% proportional colour control
4	Cyan	0-255	0-100% proportional colour control
5	Magenta	0-255	0-100% proportional colour control
6	Zoom	0-255	0-100% proportional control of the Zoom movement

DMX functions with OPTION 2 = ON

Channel	Function	Value	Description
1	Lamp	0-63	Lamp ON
		64-127	Reset
		128-255	Lamp OFF + Reset
2	Blackout Dimmer Strobe	0-5	Shutter Closed
		6-127	0-100% proportional control of the mechanical shutter
		128-159	Shutter open
		160-179	Strobe effect speed 1
		180-199	Strobe effect speed 2
		200-219	Strobe effect speed 3
		220-239	Strobe effect speed 4
240-255	Shutter open		
3	Preset Colours	0-255	62 Preset colours selection (4 DMX value step)
4	Zoom	0-255	0-100% proportional control of the Zoom movement